

Turntable Controller with track pre-selection



Art. No.: 6915

€234,90

The modern turntable control unit is suitable for analogue and digital control of the turntables from the FLEISCHMANN range. An LCD display gives a visual indication of the setting of the turntable bridge, the location of the track exits installed and shows the active track exit, together with additional functions. Symbols of the active functions give it a simple, user-friendly operation. Each track exit can be individually controlled. Because the polarity change is catered for by the switch, when rotating through 180°, the turntable is protected against short circuit. The turntable control switch is suitable for operation with 2-rail DC operation, the 3-rail AC operation, and will also operate with all digital systems - DCC, FMZ and Märklin®-Digital (contains a turntable decoder). No changes or alterations to the turntable are necessary.

Märklin is a registered trademark of the company of Gebr. Märklin & Cie. GmbH, Göppingen.