



Pos. Nr. Pos.no.	Beschreibung Description	Art.-Nr. Art.no.	Preisgruppe Price bracket
1	LOKGEHAEUSE BR 151 VERKEHRSROT Body assembly complete	10738004	038
2	LICHTLEITER-SATZ Light conductor set	13738004	---
3	ISOLATOREN-SATZ Insulator set	14738004	---
4	SCHALTER Switch	00147969	002
5	TRAVERSE F.SCHERENSTROM Traverse	00177375	006
6	PRESSLUFTSCHALTER Compressed air switch	00187380	003
7	Pfeife Whistle	00197604	003
8	ANTENNE F.7326,-27,-28,-29 Antenna	00197807	002
9	LOKFAHRGESTELL Loco chassis w/o motor	40738002	---
10	DREHGESTELLRAHMEN F.7381 Bogie framework	00417381	011
11	DREHGESTELLBLOCK KPL. Bogie block complete	00457380	018
12	DREHGESTELLBLOCK KPL. Bogie block complete	00467380	018
13	MOT.M.SCHW.O.MASSEKONTAKT DIGI Motor with flywheel	05073821	030
14	KOEHLENHALTER Carbon holder	00507801	001
15	ACHSE ZUR DREHGEST.BEFESTIGUNG Axle for bogie	00527002	002
16	RADSATZ O.Z.O.N. rot Wheelset w/o gear, w/o groove	00537017	012
17	RADSATZ M.Z.O.N. rot Wheelset with gear, w/o groove	00537018	013
18	RADSATZ M.Z.M.1 N. rot Wheelset with gear, with groove	00537037	013
19	HAFTREIFEN Traction tyre	00547002	001
20	ZAHNRAD Z:20 SCHWARZ Gear	00567101	003
21	ZAHNRAD Z:24 SCHWARZ Gear	00567131	002
22	SCHNECKE D = 4MM L = 7MM Worm gear	00567605	006
23	ROHR Brass tube	00567770	002
24	KONTAKTBUEGEL F.DREHGEST.LOKS Contact bow	00657004	013
25	LEITERPLATTE KPL. PCB complete	65716600	028
34	Schraube f. Pantograph Pantograph screw	00700303	001
28	SCHERENSTROMABNEHMER Double arm pantograph	67705500	---
26	LICHTPLATINE KPL. Light PCB	65716500	---
29	SENKSCHRAUBE KS Sunk screw	00702303	001
30	STECKPUFFER Buffer	00757002	002
31	BLATTRICHTFEDER F.KUPPLUNG N Flat straightening spring for coupling	00767006	001
32	ERSATZ-SCHLEIFKOHLEN Carbon brushes set	6518	---
33	STANDARD-KUPPLUNG Standard coupling	9521	---
	PROFI-KUPPLUNG (o. Abb.) Profi coupling (w/o illustr.)	9541	---
	LAUTSPRECHER 9x16 m. Klebepad (o. Abb.) Loudspeaker 9x16mm w. adhesive (w/o illustr.)	68701100	16
	Lautsprecheraufnahme (o. Abb.) Loudspeaker reception (w/o illustr.)	68701300	16
	SOUND-DECODER (o. Abb.) Sound decoder (w/o illustr.)	68738072	41