



796881 ET 99 01 DB		DCC	=	N
Pos. Nr. Pos.no.	Beschreibung Description	Art.-Nr. Art.no.	Preisgruppe Price bracket	
1	LOKGEHÄUSE KPL. Loco body assembly complete	10796801	031	
2	LOKRAHMEN F.87968 loco chassis	01179681	028	
3	SCHALTER switch	00147969	002	
4	BESCHWERUNG F.87968 ballast	00167968	014	
5	TRAVERSE F. SCHERENSTROM traverse for double arm pantograph	00177375	006	
6	GLOCKE bell	00197501	004	
7	HORN horn	00197601	004	
8	REINIGUNGSSCHEIBEN Polishing disc	00357969	001	
9	SCHLEIFTELLER M.FEDER Polishing disc base with spring	00367968	009	
10	LOKFAHRGESTELL O.MOTOR loco chassis w/o motor	04079681	037	
11	FAHRGESTELL loco chassis	00417969	022	
12	ABDECKPLATTE-SATZ cover plate set	00437969	009	
13	MOTOR O.SCHW.M.MASSEKONTAKT Motor with flywheel w/o ground contactor	00507968	028	
14	KOHLHALTER carbon holder	00507801	001	
15	ANTRIEBSACHSE drive wheel	00527218	018	
16	RADSATZ M.Z.F.7218,7968 Wheelset complete with gear wheel	00537001	011	
17	RITZEL sprocket wheel	00567602	003	
18	RITZEL sprocket wheel	00567603	003	
19	ENTSTOERDROSSEL Suppressor choke	00644101	007	
20	ENTSTOERKONDENSATOR Anti-noise capacitor	00644207	006	
21	SCHERENPANTOGRAPH ROT AA double arm pantograph	00677006	018	
22	SENKSCHRAUBE KS countersunk screw	00702303	001	
23	STECKPUFFER plug-in buffer	00757002	002	
24	BLATTRICHTFEDER F.KUPPLUNG N Flat straightening spring for coupling	00767006	001	
25	ERSATZ-SCHLEIFKOHLEN carbon brushes set	6518	---	
26	STANDARD-KUPPLUNG standard coupling	9521	---	
27	PROFI-KUPPLUNG profi coupling	9541	---	