



Pos. Nr. Pos.no.	Beschreibung Description	Art.-Nr. Art.no.	Preisgruppe Price bracket
734104	DB BR 141	=	N
734174		=	N
1	LOKGEHÄUSE KPL. Loco body assembly	144430	037
2	BELEUCHTUNGSABDECKUNG -SATZ Light cover -set	12734101	011
3	FLUTLICHTLEITER Light conductor	13734101	006
4	ISOLATOREN, SCHALTER-SATZ Set or isolators, switch set	00147327	015
5	SCHALTER Switch	00147969	002
6	STIRNFENSTER-SATZ Front window	00157327	012
7	TRAVERSE F. SCHERENSTROM Traverse for double arm pantograph	00177375	006
8	PRESSLUFTSCHALTER Compressor switch	00187326	006
9	PFEIFE Whistle	00197604	003
10	ARMATURENTEIL Fittings assy	33734103	009
11	ADAPTER F. ELLOKS Adaptor for electronic loco	00387000	002
12	GRUNDRAHMEN Base frame	40734103	018
13	DREHGESTELLRAHMEN Bogie framework	00417326	011
14	DREHGESTELLBLOCK Bogie block	00457327	017
15	MOTOR M.SCHW.O.MASSEKONTAKT Motor w. flywheel w/o ground contactor	00507340	029
16	KOEHLENHALTER Carbon holder	00507801	001
17	ACHSE Axle	00527006	001
18	RADSATZ M.Z.O.N. Wheelset compl.w.gear wh. w/o groove	53714800	014
19	RADSATZ M.Z.M.1 NUT Wheelset complete w. gear wh., 1groove	53714900	014
20	HAFTREIFEN Traction tyre	00547002	001
21	ZAHNRAD Z:17 Gear wheel	00567132	002
22	SCHNECKE D = 4MM L = 8MM Worm gear	00567604	006
23	KONTAKTBUEGEL Contact plate assy	00657023	001
24	TS - GRIFFE Part set - Handrails	19791900	008
25	LEITERPLATTE PCB	65715500	028
26	BRÜCKENSTECKER Jumper	00664005	013
27	SCHERENPANTOGRAPH Double arm pantograph	00677006	018
28	SCHRAUBE Screw	00702303	001
29	STECKPUFFER (GEWÖLBT) Plug-in buffer (curved)	00757011	002
30	STECKPUFFER (FLACH) Plug-in buffer (flat)	00757012	002
31	PUFFERBOHLE KPL. Frontside framework complete	75734101	012
32	ERSATZ-SCHLEIFKOHLEN carbon brushes set	6518	---
33	STANDARD STECKKUPPLUNG Standard plug-in coupling	9525	---
Sound			
34	LAUTSPRECHER Loudspeaker	68701100	016
35	LAUTSPRECHERAUFNAHME Loudspeaker reception	68701200	016
36	SOUNDDECODER Sound decoder	68732871	041